

QUICK START GUIDE

Apollo510B EVB (EVB Revision 2.0)

Ultra-low Power Apollo SoC Family

Doc. ID: QS-A510B-1p2

Document Revision 1.2, October 2026



Legal Information and Disclaimers

AMBIQ MICRO BELIEVES THE INFORMATION IN THIS DOCUMENT IS ACCURATE AT THE TIME OF PUBLICATION. HOWEVER, THE INFORMATION MAY CONTAIN TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. AMBIQ MICRO RESERVES THE RIGHT TO MAKE CORRECTIONS, MODIFICATIONS, ENHANCEMENTS, IMPROVEMENTS, OR OTHER CHANGES TO ITS PRODUCTS (AND DOCUMENTATION) AT ANY TIME WITHOUT NOTICE.

INFORMATION IN THIS DOCUMENT IS PROVIDED SOLELY TO ENABLE THE USE OF AMBIQ MICRO PRODUCTS AND IS PROVIDED "AS IS." NO LICENSE IS GRANTED TO DESIGN OR FABRICATE ANY INTEGRATED CIRCUITS BASED ON THE INFORMATION IN THIS DOCUMENT. THIS DOCUMENT MAY NOT BE USED IN CONNECTION WITH ANY LEGAL ANALYSIS CONCERNING THE AMBIQ MICRO PRODUCTS DESCRIBED HEREIN. AMBIQ MICRO DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT.

AMBIQ MICRO PRODUCTS ARE SOLD SUBJECT TO AMBIQ MICRO'S TERMS AND CONDITIONS OF SALE; SOFTWARE IS PROVIDED PURSUANT TO APPLICABLE LICENSE TERMS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, IS GRANTED UNDER ANY INTELLECTUAL PROPERTY RIGHT OF AMBIQ MICRO OR ANY THIRD PARTY BY THIS DOCUMENT.

CUSTOMERS ARE SOLELY RESPONSIBLE FOR THE DESIGN, VALIDATION, TESTING, AND SECURITY OF THEIR PRODUCTS AND APPLICATIONS, INCLUDING THE SPECIFIC MANNER IN WHICH AMBIQ MICRO'S PRODUCTS ARE INCORPORATED. "TYPICAL" PARAMETERS ARE FOR REFERENCE ONLY AND IT IS THE CUSTOMER'S RESPONSIBILITY TO VALIDATE "TYPICAL" SPECIFICATIONS FOR THEIR APPLICATION.

AMBIQ MICRO PRODUCTS ARE NOT DESIGNED OR AUTHORIZED FOR USE IN APPLICATIONS WHERE PRODUCT FAILURE COULD RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("HIGH-RISK APPLICATIONS") WITHOUT EXPRESS WRITTEN APPROVAL. IF PRODUCTS ARE USED IN HIGH-RISK APPLICATIONS WITHOUT SUCH APPROVAL, THE CUSTOMER SHALL INDEMNIFY AND HOLD HARMLESS AMBIQ MICRO AND ITS AFFILIATES FROM ALL RESULTING CLAIMS, DAMAGES, COSTS, AND EXPENSES, INCLUDING REASONABLE ATTORNEYS' FEES. IN NO EVENT SHALL AMBIQ MICRO BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES, INCLUDING LOST PROFITS OR DATA, ARISING FROM THE USE OF THIS DOCUMENT OR ANY PRODUCT.

"AMBIQ", "APOLLO", "SPOT", AND COMBINATIONS THEREOF ARE TRADEMARKS OF AMBIQ MICRO, INC. OTHER PRODUCT NAMES USED IN THIS PUBLICATION ARE FOR IDENTIFICATION PURPOSES ONLY AND MAY BE TRADEMARKS OF THEIR RESPECTIVE COMPANIES.

Table of Content

1. Introduction	6
2. Document Revision History.....	6
3. Reference Documents and Software	7
4. Overview of the Apollo510B EVB	8
5. EVB Kit Contents	8
6. Initial Setup	9
7. Software Setup	9
8. Board Layout.....	10
9. Secure Boot on the Apollo510B SoC.....	15
10. Header Pin Assignments	16
11. Debug Interface	19
12. Software Development Tools.....	21
13. Power Supply Options and Measuring Current.....	22
14. EVB Known Issues	27

List of Figures

Figure 1. EVB Top View.....	10
Figure 2. EVB Bottom View	11
Figure 3. EVB Major Components	12
Figure 4. EVB Top Side Components.....	13
Figure 5. EVB Bottom Side Components.....	14
Figure 6. J14/J15 MikroBUS Headers - Function Options	16
Figure 7. J8 General Purpose Headers - Function Options.....	16
Figure 8. J7 High-speed Header - Function Options	17
Figure 9. Board View of J7 High-speed Header	18
Figure 10. On-board J-Link Debug Connector (MAIN USB).....	19
Figure 11. J2 Debug-In Header	20
Figure 12. J6 External Supply Header	22
Figure 13. J4 Power Supply Jumper Connections.....	23
Figure 14. J4 Default Jumper Configuration	23
Figure 15. J5 Power Supply Jumper Connections.....	24
Figure 16. J5 Default Jumper Configuration	24
Figure 17. USB Load Switch Circuit.....	25
Figure 18. VDD18/MIPI Load Switch Circuit.....	25
Figure 19. J3 Voltage Test Points Header	26
Figure 20. Board View of J3 Voltage Test Points Header.....	26

List of Tables

Table 1: Document Revision History..... 6

Table 2: J8 Default Solder Bridge Configuration Table..... 16

Table 3: J4 Default Jumper Configuration Table 23

Table 4: J5 Default Jumper Configuration Table 24

1. Introduction

This document provides guidance for setting up the Apollo510B Evaluation Board (EVB), revision 2.0, part number AP510BEVB, to get started executing code examples, measuring power consumption in various configurations, and beginning software development.

FCC Regulatory Notice

This kit has not been authorized under the rules of the FCC. It is designed to:

1. Allow product developers to evaluate electronic components, circuitry or software associated with the kit to determine whether to incorporate such items in a finished product.
2. Enable software developers to write software applications for use with the end product.

This kit is not a finished product and may not be resold or otherwise marketed unless all required FCC authorizations are first obtained. **Developers using this reference design in their product are responsible for obtaining all required FCC equipment authorizations.**

Operation of this kit is subject to the condition that it does not cause harmful interference to licensed radio stations and that it accepts any harmful interference received. Unless the assembled kit is designed to operate under part 15, part 18, or part 95 of 47 CFR Chapter I - FCC, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of the latter chapter.

2. Document Revision History

Table 1: Document Revision History

Rev #	Date	Description
1.0	Sep 2025	Document initial public release
1.1	Nov 2025	Added important note about installing the Seggar J-Link software in Software Development Tools section.
1.2	Oct 2026	▪ Updated the components list in Figure 3. ▪ Added “EVB Known Issues”. ▪ Removed “Ordering Information”.

3. Reference Documents and Software

The following resources provide additional information for developing with the Apollo510B EVB. The latest versions are available from the Ambiq Content Portal:

- EVB Schematic
- Apollo510B Datasheet
- Apollo510/Apollo510B Errata List
- AmbiqSuite SDK

4. Overview of the Apollo510B EVB

The Apollo510B EVB has the following features:

- **Processor**
 - Apollo510B Arm® Cortex®-M55 based SoC in the BGA package
- **Connectivity**
 - USB Type-C connector for power, download, and debug
 - USB Type-C connector for power and data to the Apollo510B SoC
 - On-board SEGGER J-Link debugger
 - Debug-in port for SWD or ETM
- **Power and Reset**
 - Power slide switch with LED power indicator
 - Reset push button
- **User Interface**
 - Three user-controlled LEDs
 - Two push buttons for application use
- **External Memory**
 - MSPI x16 (Hex) PSRAM
 - SDIO 8 GB eMMC⁽¹⁾
- **Expansion**
 - High-speed connector for interfacing with displays and/or high-speed memory
 - MikroBUS socket interface
 - General-purpose male header for I/O and power access to a shield board
- **RF**
 - RF switch/connector for BLE PHY testing
- **Power Measurement**
 - Test points for voltage measurements
 - Jumpers for current measurements
 - Solder bridge options

Although the EVB includes specific hardware for RF testing, it can also be used for non-radio applications. If the radio functionality is not required, simply disregard these features.

5. EVB Kit Contents

The EVB Kit includes the following items:

- Apollo510B Evaluation Board (EVB), revision 2.0
- USB Type-C cable
- Four adhesive-backed rubber feet
- Extra jumpers

CAUTION

The EVB has components loaded on the back of the board. Care should be taken to not damage these components. The included rubber feet should be applied to the bottom of the board to prevent direct contact between the components and a desk surface.

1. The eMMC has been de-populated. See "EVB Known Issues" on page 27.

6. Initial Setup

The EVB comes with jumpers pre-configured for default operation. To power on the EVB:

1. Connect the USB-C cable from a USB port on the host PC to the J-Link USB connector J16 (see component 21 in Figure 3 on page 12) on the EVB
2. Turn on the power switch SW4 (see component 24 in Figure 3 on page 12).
3. Verify the green LED (see component 1 in Figure 3 on page 12) next to the power switch is illuminated.

7. Software Setup

The AmbiqSuite SDK contains software libraries, tools, and example applications for the EVB. Download the latest version of the AmbiqSuite SDK from the Ambiq Content Portal.

Pre-built examples are located in:

`/boards/apollo510b_evb/examples`

Program the example applications at address 0x410000.

8. Board Layout

The following figures show the board layout, its major components and the location of all components.



Figure 1. EVB Top View




Figure 2. EVB Bottom View




Figure 3. EVB Major Components




Figure 4. EVB Top Side Components




Figure 5. EVB Bottom Side Components

9. Secure Boot on the Apollo510B SoC

The on-board Apollo510B SoC is preprogrammed with a Secure Bootloader and an uninitialized Customer Info Space, referred to as INFO0. Initial provisioning of the part would include programming a valid INFO0 and programming the main firmware image in the flash. The Apollo510B EVB is shipped with the INFO0 configuration pre-programmed with optimal settings for the EVB layout which would include the following features/settings:

1. Default boot to non-secure mode
2. Enable Boot Override to Push Button on GPIO46 (OTP setting) - BTN0 (SW2).
3. Enable wired updates over UART1
 - A. UART1 is mapped to J-Link (OTP Setting).
 - B. Baud rate is 115200 bps, no-parity, 8-bit data length, no flow control.
 - C. Timeout is 5 seconds.

For reference, the following settings are programmed into INFO0 on the Apollo510B SoC resident on the EVB:

- Secure Bootloader (SBL) interface is configured to UART1 using GPIO12 and GPIO14, which allows secure boot to be performed over the J-Link COM interface of the EVB.
- SBL override pin is configured to GPIO46 which is Button 0 (SW2) on the EVB.

For information on changing the INFO0 settings as well as using the Secure Bootloader, please refer to the README.txt file found in the `tools\apollo510_scripts` folder of the latest SDK release supporting the Apollo5 family. This folder contains a number of Python scripts to demonstrate generation of INFO0 settings, customer main images, and the creation of images for the Wired Update protocol over UART.

Please consult your Ambiq sales team for any additional documentation on INFO0 settings or Secure Bootloader, and visit the Ambiq Content Portal for security documentation for the Apollo5 family.




Figure 9. Board View of J7 High-speed Header

11. Debug Interface

Figure 10 shows the Apollo510B EVB set up for standard debug using the on-board J-Link debugger, selected by the PWR_SRC header (J17) set to VBUS_JLINK, connected through the MAIN USB connector (J16).




Figure 10. On-board J-Link Debug Connector (MAIN USB)

The debug interface is supported by standard J-Link drivers from Segger. Please refer to “Software Development Tools” on page 21 for more details on J-Link debug support.

11.1 Use of External Debugger

This EVB also supports the use of an external SWD debug interface through a 20-pin debug-in header (DEBUG HDR – J2) as shown in Figure 11. See the EVB schematic for connector pinout.




Figure 11. J2 Debug-In Header

No jumper changes are required to use an external debug adapter. Simply connect the external debug adapter with a ribbon cable connector to the “DEBUG HDR” header.

NOTE: Remove protective guard before attempting to connect to the debug header.

12. Software Development Tools

The standard Segger J-Link debug interface is used on the Apollo510B EVB. Regardless of the IDE used, please install the Segger J-Link software - see <https://www.segger.com/downloads/jlink>. Refer to the AmbiqSuite SDK for version numbers of the IDEs used for that release, and see the \AmbiqSuite\debugger_updates\ folder in the AmbiqSuite SDK for interim updates for Keil, IAR, and JLINK.

IMPORTANT NOTE

When installing the Segger J-Link software described above, it may be necessary to select the “Install Legacy USB Driver” option in order to properly enable the USB connection. This option is not selected by default in the Segger installation setup dialog box, so the checkbox has to be checked to install the legacy USB driver. (This is the only default installation option that needs to be changed when installing the software.)

13. Power Supply Options and Measuring Current

The Apollo510B EVB is intended to operate off a 5 V supply, which is used to generate down-stream voltages.

There are three options for the main power supply (VDD_MCU) for the EVB SoC :

- Operate at a nominal 1.8 V regulated down from the VDD_5V supply to source the on-board power rail SYS_VDD (default). Note that this voltage can be adjusted to 1.9 V by cutting SB3 shown on the Power Supplies page of the EVB schematic.
- Operate at 1.8 V via the low-noise VDD1V8_LN output of the regulated-down VDD_3V3 supply.
- Provide externally-supplied power via J6 in Figure 12.

NOTE: If externally supplying VDD_MCU and/or VDDAUDA, which powers the analog audio and XTALHS crystal of Apollo510B, from VDD_EXT, the supplied voltage range must be in the specified range for the rail(s) being supplied:

- If externally supplying VDD_MCU and VDDAUDA, the allowable range is 1.71 V to 1.98 V.
- If supplying VDDAUDA from the VDD1V8_LN regulated output and not by externally supplied VDD_MCU, the allowable VDD_EXT range is 1.71 V to 2.2 V.
- If externally supplying VDDAUDA but not VDD_MCU, the allowable VDD_EXT range is 1.62 V to 1.98 V.




Figure 12. J6 External Supply Header

The EVB utilizes jumpers for connecting and disconnecting rails from power supplies, whether generated on-board or off-board. The following figures show the jumper connection strategy among various on-board power supplies and the SoC's power rails.

Figure 13 shows the power sourcing options for VDD_MCU.




Figure 13. J4 Power Supply Jumper Connections

The J4 default jumper configuration is as shown in Figure 14 and in Table 3.




Figure 14. J4 Default Jumper Configuration

Table 3: J4 Default Jumper Configuration Table

Power Supply Source	From Header Pin	To Header Pin	Power Supply Destination
SYS_VDD	J4-1	J4-2	VDD_MCU
VDD1V8_LN	J4-8	J4-7	VDDAUDA

Figure 15 shows the power sourcing for VDDH1, VDDH2, VDDH3, and BLE_VBAT2. VDDH1, VDDH2 and BLE_VBAT2 are always sourced from VDD_MCU, and VDDH3 is always sourced from VDD_1V2. This header and jumpers are here solely for current measurements.




Figure 15. J5 Power Supply Jumper Connections

The J5 default jumper configuration is as shown in Figure 16 and Table 4.




Figure 16. J5 Default Jumper Configuration

Table 4: J5 Default Jumper Configuration Table

Power Supply Source	From Header Pin	To Header Pin	Power Supply Destination
VDD_MCU	J5-1	J5-2	VDDH1
VDD_MCU	J5-3	J5-4	VDDH2
VDD_1V2	J5-5	J5-6	VDDH3
VDD_MCU	J5-7	J5-8	BLE_VBAT2

13.1 USB and VDD18/MIPI Load Switch Circuits

Figure 17 shows the USB load switch circuit producing the voltage supplied to VDDUSB33_AP5 and VDDUSB0P9_AP5.




Figure 17. USB Load Switch Circuit

Similarly, Figure 18 shows the load switch circuit that produces the voltage supplied to the MIPI DPHY VDD18.




Figure 18. VDD18/MIPI Load Switch Circuit

13.2 Monitoring or Externally Supplying Supply Voltages

As shown in Figure 19 and Figure 20, header J3 provides easy access to the various system and chip-level power supplies present on the EVB. These can be used to monitor voltage or provide externally generated power to each specific rail after assuring that the on-board supply has been disconnected.




Figure 19. J3 Voltage Test Points Header

The J3 and J5 headers are as shown in Figure 20. The header guard may need to be removed before connecting to or probing the header pins.




Figure 20. Board View of J3 Voltage Test Points Header

13.3 Measuring Current

Current consumption of the Apollo510B EVB can be measured by connecting an ammeter between the corresponding DUT supplies. Refer to Figure 12 or Figure 15 to measure the current draw from the power supply of interest. Before using an ammeter, turn the power off, remove the corresponding jumper and install the ammeter properly prior to powering the board back on. When the current measurements have been completed, reposition the jumper at its former location.

14. EVB Known Issues

The eMMC has been de-populated on this board revision due to supply constraints, but the pads are on the board if the user wants to use their own footprint compatible eMMC component.

The associated components remain populated: R42, R43, R44, C51, C52, C53, C54, and C55.

This page is intentionally left blank.



©2026 Ambiq Micro, Inc. All rights reserved.

Ambiq Micro, Inc.

6500 River Place Boulevard, Building 7,

Suite 200, Austin, TX 78730-1156

www.ambiq.com/

sales@ambiqmicro.com

<https://support.ambiqmicro.com>

+1 (512) 879-2850

QS-A510B-1p2

Version 1.2

October 2026