

QUICK START GUIDE

Apollo510 Lite Series EVB (EVB Revision 3.0)

Ultra-low Power Apollo SoC Family

Doc. ID: QS-A510DL-3p0

Document Revision 3.0, September 2026



Legal Information and Disclaimers

AMBIQ MICRO BELIEVES THE INFORMATION IN THIS DOCUMENT IS ACCURATE AT THE TIME OF PUBLICATION. HOWEVER, THE INFORMATION MAY CONTAIN TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. AMBIQ MICRO RESERVES THE RIGHT TO MAKE CORRECTIONS, MODIFICATIONS, ENHANCEMENTS, IMPROVEMENTS, OR OTHER CHANGES TO ITS PRODUCTS (AND DOCUMENTATION) AT ANY TIME WITHOUT NOTICE.

INFORMATION IN THIS DOCUMENT IS PROVIDED SOLELY TO ENABLE THE USE OF AMBIQ MICRO PRODUCTS AND IS PROVIDED "AS IS." NO LICENSE IS GRANTED TO DESIGN OR FABRICATE ANY INTEGRATED CIRCUITS BASED ON THE INFORMATION IN THIS DOCUMENT. THIS DOCUMENT MAY NOT BE USED IN CONNECTION WITH ANY LEGAL ANALYSIS CONCERNING THE AMBIQ MICRO PRODUCTS DESCRIBED HEREIN. AMBIQ MICRO DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT.

AMBIQ MICRO PRODUCTS ARE SOLD SUBJECT TO AMBIQ MICRO'S TERMS AND CONDITIONS OF SALE; SOFTWARE IS PROVIDED PURSUANT TO APPLICABLE LICENSE TERMS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, IS GRANTED UNDER ANY INTELLECTUAL PROPERTY RIGHT OF AMBIQ MICRO OR ANY THIRD PARTY BY THIS DOCUMENT.

CUSTOMERS ARE SOLELY RESPONSIBLE FOR THE DESIGN, VALIDATION, TESTING, AND SECURITY OF THEIR PRODUCTS AND APPLICATIONS, INCLUDING THE SPECIFIC MANNER IN WHICH AMBIQ MICRO'S PRODUCTS ARE INCORPORATED. "TYPICAL" PARAMETERS ARE FOR REFERENCE ONLY AND IT IS THE CUSTOMER'S RESPONSIBILITY TO VALIDATE "TYPICAL" SPECIFICATIONS FOR THEIR APPLICATION.

AMBIQ MICRO PRODUCTS ARE NOT DESIGNED OR AUTHORIZED FOR USE IN APPLICATIONS WHERE PRODUCT FAILURE COULD RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("HIGH-RISK APPLICATIONS") WITHOUT EXPRESS WRITTEN APPROVAL. IF PRODUCTS ARE USED IN HIGH-RISK APPLICATIONS WITHOUT SUCH APPROVAL, THE CUSTOMER SHALL INDEMNIFY AND HOLD HARMLESS AMBIQ MICRO AND ITS AFFILIATES FROM ALL RESULTING CLAIMS, DAMAGES, COSTS, AND EXPENSES, INCLUDING REASONABLE ATTORNEYS' FEES. IN NO EVENT SHALL AMBIQ MICRO BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES, INCLUDING LOST PROFITS OR DATA, ARISING FROM THE USE OF THIS DOCUMENT OR ANY PRODUCT.

"AMBIQ", "APOLLO", "SPOT", AND COMBINATIONS THEREOF ARE TRADEMARKS OF AMBIQ MICRO, INC. OTHER PRODUCT NAMES USED IN THIS PUBLICATION ARE FOR IDENTIFICATION PURPOSES ONLY AND MAY BE TRADEMARKS OF THEIR RESPECTIVE COMPANIES.

Table of Content

1. Introduction	6
2. Document Revision History.....	6
3. Reference Documents and Software	7
4. Overview of the Apollo510 Lite Series EVB	8
5. EVB Kit Contents	8
6. Initial Setup	9
7. Software Setup	9
8. Board Layout.....	10
9. Secure Boot on the Apollo510 Lite Series SoC	14
10. Header Pin Assignments	15
11. Debug Interface	18
12. Software Development Tools.....	20
13. Power Supply Options and Measuring Current.....	21
14. EVB Known Issues	31
15. Ordering Information	32

List of Figures

Figure 1. EVB Top View.....	10
Figure 2. EVB Bottom View	10
Figure 3. EVB Major Components	11
Figure 4. EVB Top Side Components.....	12
Figure 5. EVB Bottom Side Components.....	13
Figure 6. J14/J15 MikroBUS Headers - Function Options	15
Figure 7. J8/J13 General Purpose Headers - Function Options	15
Figure 8. J7 High-speed Header - Function Options	16
Figure 9. Board View of J7 High-speed Header	17
Figure 10. On-board J-Link Debug Connector (MAIN USB).....	18
Figure 11. J2 Debug-In Header	19
Figure 12. J6 External Supply Header	21
Figure 13. J10 Power Supply Jumper Connections.....	22
Figure 14. J10 Default Jumper Configuration	22
Figure 15. Power Supply Jumper Connections.....	23
Figure 16. J4 Default Jumper Configuration	24
Figure 17. USB 3.3 V and Display Load Switch Circuit	25
Figure 18. J3 and J5 Voltage Test Point Headers	26
Figure 19. Board View of J3 and J5 Voltage Test Points Headers	26
Figure 20. Joulescope to EVB Power Connections	27
Figure 21. Download Messages in J-Link SWO Viewer	28

List of Tables

Table 1: Document Revision History.....	6
Table 2: J10 Configuration Table (Default Configuration in Bold).....	23
Table 3: J4 Jumper Configuration (Default Configuration in Bold).....	24
Table 4: Example of HCI_LE_Receiver_Test Command Format.....	29
Table 5: Example of HCI_LE_Test_End Command Format.....	29
Table 6: Example of HCI_LE_Test_End Command Format.....	29
Table 7: Example of HCI_LE_Test_End Command Format.....	30
Table 8: EVB Ordering Information.....	32

1. Introduction

This document provides guidance for setting up the Apollo510 Lite Series Evaluation Board (EVB), revision 3.0, part number AP510DLEVB, to get started executing code examples, measuring power consumption in various configurations, and beginning software development.

FCC Regulatory Notice

This kit has not been authorized under the rules of the FCC. It is designed to:

1. Allow product developers to evaluate electronic components, circuitry or software associated with the kit to determine whether to incorporate such items in a finished product.
2. Enable software developers to write software applications for use with the end product.

This kit is not a finished product and may not be resold or otherwise marketed unless all required FCC authorizations are first obtained. **Developers using this reference design in their product are responsible for obtaining all required FCC equipment authorizations.**

Operation of this kit is subject to the condition that it does not cause harmful interference to licensed radio stations and that it accepts any harmful interference received. Unless the assembled kit is designed to operate under part 15, part 18, or part 95 of 47 CFR Chapter I - FCC, the operator of the kit must operate under the authority of an FCC license holder or must secure an experimental authorization under part 5 of the latter chapter.

2. Document Revision History

Table 1: Document Revision History

Rev #	Date	Description
1.0	Dec 2025	▪ Initial release
2.0	June 2026	▪ Updated for EVB Revision 2.0 ▪ Updated Legal Information and Disclaimers ▪ Added Power Consumption Measurement Procedure for Apollo510 Lite ▪ Updated EVB and SoC Ordering Information tables
3.0	September 2026	▪ Updated for EVB Revision 3.0 ▪ Added the EVB's pre-programmed INFO0 configuration and secure boot settings information in "Secure Boot on the Apollo510 Lite Series SoC" on page 14 ▪ Replaced BLE with Radio Subsystem in "Radio Subsystem Power Consumption Measurement for the Apollo510D Lite SoC" on page 27 ▪ Removed the Ordering Information table

3. Reference Documents and Software

The following resources provide additional information for developing with the Apollo510 Lite EVB. The latest versions are available from the Ambiq Content Portal:

- EVB Schematic
- Apollo510 Lite Series Datasheet
- Apollo510 Lite Series Errata List
- AmbiqSuite SDK

4. Overview of the Apollo510 Lite Series EVB

The Apollo510 Lite Series EVB has the following features:

- **Processor**
 - Apollo510 Lite Series Arm® Cortex®-M55 based SoC in the BGA package
- **Connectivity**
 - USB Type-C connector for power/download/debug
 - USB Type-C connector for power/data to Apollo510 Lite Series SoC
 - Debug-in port (SWD/ETM)
- **Power and Reset**
 - Power slide switch with LED power indicator
 - Reset push button
- **User Interface**
 - Three user-controlled LEDs
 - Two push buttons for application use
- **External Memory**
 - MSPI x16 (Hex) PSRAM
 - SDIO 8 GB eMMC⁽¹⁾
- **Expansion**
 - High-speed connector for interfacing to add-on cards
 - MikroBUS socket interface (3.3V or 1.8V interface)
 - General-purpose headers
- **RF**
 - RF switch/connector for radio PHY testing
- **Power Measurement**
 - Test points for voltage measurements
 - Current measurement jumpers
 - Solder bridge options for power supply flexibility and peripheral access options
- **RoHS compliant**

Although the EVB includes specific hardware for RF testing, it can also be used for non-radio applications. If the radio functionality is not required, simply disregard these features.

5. EVB Kit Contents

The EVB Kit includes the following items:

- Apollo510 Lite Series Evaluation Board (EVB), revision 3.0
- USB Type-C cable
- Four adhesive-backed rubber feet
- Extra jumpers

CAUTION

The EVB has components loaded on the back of the board. Care should be taken to not damage these components. The included rubber feet should be applied to the bottom of the board to prevent direct contact between the components and a desk surface.

1. See "EVB Known Issues" on page 31.

6. Initial Setup

The EVB comes with jumpers pre-configured for default operation. To power on the EVB:

1. Connect the USB-C cable from a USB port on the host PC to the J-Link USB connector J16 (see component 21 in Figure 3 on page 11) on the EVB
2. Turn on the power switch SW4 (see component 1 in Figure 3 on page 11).
3. Verify the green LED (see component 2 in Figure 3 on page 11) next to the power switch is illuminated.

7. Software Setup

The AmbiqSuite SDK contains software libraries, tools, and example applications for the EVB. Download the latest version of the AmbiqSuite SDK from the Ambiq Content Portal.

Pre-built examples are located in:

`/boards/apollo510dL_evb/examples`

Program the example applications at address 0x410000.

8. Board Layout

The following figures show the board layout, its major components and the location of all components.



Figure 1. EVB Top View





Figure 2. EVB Bottom View



1. Power Switch
2. Power LED
3. Debug Header
4. Dual-Row Header #1
5. JLINK Controller
6. Dual-Row Header #2
7. MikroBUS Connectors (2x)
8. High Speed Connector
9. Apollo510 Lite Series BGA MCU (AP510DLA-CBR)
10. PCB Trace Antenna
11. RF Switch/Connector
12. MSPI0 (APS512XXN-AOB4BI-WBRZ)
13. User Buttons (2x)
14. eMMC (IS21EF08G-JCLI) - Not populated. See See "EVB Known Issues" on page 31.
15. Power Configuration Header
16. Reset Button
17. User LEDs (3x)
18. Power Test Points Header
19. Apollo510 Lite Series USB Connector
20. Power Source Header
21. JLINK USB Connector
22. External Power Connector
23. MCU Supply Selection
24. MikroBUS Interface Power Selection

Figure 3. EVB Major Components




Figure 4. EVB Top Side Components




Figure 5. EVB Bottom Side Components

9. Secure Boot on the Apollo510 Lite Series SoC

The on-board Apollo510 Lite Series SoCs are preprogrammed with a Secure Bootloader and an uninitialized Customer Info Space, referred to as INFO0. Initial provisioning of the part would include programming a valid INFO0 and programming the main firmware image in the flash.

The Apollo510 Lite Series EVB is shipped with the INFO0 configuration pre-programmed with optimal settings for the EVB layout which would include the following features/settings:

1. Default boot to non-secure mode
2. Enable Boot Override to Push Button on GPIO18 (OTP setting) - BTN0 (SW3)
3. Enable wired updates over UART0
 - A. UART0 is mapped to J-Link (OTP Setting).
 - B. Baud rate is 115200 bps, no-parity, 8-bit data length, no flow control
 - C. Timeout is 5 seconds

For reference, the following settings are programmed into INFO0 on the Apollo510DL SoC resident on the EVB:

- Secure Bootloader (SBL) interface is configured to UART0 using GPIO14 and GPIO15, which allows secure boot to be performed over the J-Link COM interface of the EVB.
- SBL override pin is configured to GPIO18 which is Button 0 (SW3) on the EVB.

For information on changing the INFO0 settings as well as using the Secure Bootloader, please refer to the README.txt file found in the `tools\apollo510L_scripts` folder of the latest SDK release supporting the Apollo510 Lite Series. This folder contains a number of Python scripts to demonstrate generation of INFO0 settings, customer main images, and the creation of images for the Wired Update protocol over UART.

Please consult your Ambiq sales team for any additional documentation on INFO0 settings or Secure Bootloader, and visit the Ambiq Content Portal for security documentation for the Apollo510 Lite Series.

10. Header Pin Assignments

This section provides an overview of the Apollo510 Lite Series EVB connectivity and pin function options.

10.1 MikroBUS Headers

The Apollo510 Lite Series EVB provides a MikroBUS header to enable rapid prototyping. The interface is accessed through headers J14 and J15 as shown in Figure 6. The IO Voltage for this interface is selected by a jumper on J11 labeled MBUS_IF_PWR. Place the jumper between pins 1-2 for 3.3V (default) or pins 2-3 for 1.8V.




Figure 6. J14/J15 MikroBUS Headers - Function Options

10.2 General Purpose Headers

Function options for pins of general purpose headers J8 and J13 are as shown in Figure 7.




Figure 7. J8/J13 General Purpose Headers - Function Options

There are 2 solder bridges (SB1 and SB2) which will connect the I3C signals (I3C_SCL and I3C_SDA) from the GPIO header (J8) to 2 pins on the high-speed header (J7). By default, these solder bridges are shorted and the connection is made. These 2 solder bridges are located on the back of the EVB.

10.3 High-speed Header

Function options for pins of the high-speed header J7 are as shown in Figure 8.




Figure 8. J7 High-speed Header - Function Options

Pin 82 of the high-speed header can be connected to either GPIO96 or GPIO58 using solder bridge. By default, this is connected to GPIO96.

Figure 9 shows the board view of the J7 high-speed header which is located on the right edge of the EVB. The protective tape should be removed from the header before use.




Figure 9. Board View of J7 High-speed Header




Figure 11. J2 Debug-In Header

No jumper changes are required to use an external debug adapter. Simply connect the external debug adapter with a ribbon cable connector to the “DEBUG HDR” header.

NOTE: Remove protective guard before attempting to connect to the debug header.

12. Software Development Tools

The standard Segger J-Link debug interface is used on the Apollo510 Lite Series EVB. Regardless of the IDE used, please install the Segger J-Link software - see <https://www.segger.com/downloads/jlink>. Refer to the AmbiqSuite SDK for version numbers of the IDEs used for that release, and see the \AmbiqSuite\debugger_updates\ folder in the AmbiqSuite SDK for interim updates for Keil and JLINK.

IMPORTANT NOTE

When installing the Segger J-Link software described above, it may be necessary to select the “Install Legacy USB Driver” option in order to properly enable the USB connection. This option is not selected by default in the Segger installation setup dialog box, so the checkbox has to be checked to install the legacy USB driver. (This is the only default installation option that needs to be changed when installing the software.)

13. Power Supply Options and Measuring Current

The Apollo510 Lite Series EVB is intended to operate off a 5 V supply, which is used to generate downstream voltages.

There are two options for the main power supply (VDD_MCU) for the EVB SoC (configured via J10):

- Operate at a nominal 1.8 V regulated down from the VDD_5V supply to source the on-board power rail SYS_VDD (default). Note that this voltage can be adjusted to 1.9 V by cutting SB3 shown on the Power Supplies page of the EVB schematic.
- Provide externally-supplied power via J6 in Figure 12.

NOTE: If externally supplying VDD_MCU from VDD_EXT, the supplied voltage range is 1.71 V to 2.2 V.




Figure 12. J6 External Supply Header

The EVB utilizes jumpers for connecting and disconnecting rails from power supplies, whether generated on-board or off-board. The following figures show the jumper connection strategy among various on-board power supplies and the SoC's power rails.

Figure 13 shows the power sourcing options for VDD_MCU.

VDD0P9 is connected to VDDUSB0P9_AP5L via a jumper on pins 5-6 of J10. VDD0P9 is a 0.9 V supply generated by an LDO in the SoC and is used to power the 0.9 V supply for the USB. The header will allow current measurement on that rail.




Figure 13. J10 Power Supply Jumper Connections

The J10 default jumper configuration is as shown in Figure 14 and in bold in Table 2.




Figure 14. J10 Default Jumper Configuration


Table 2: J10 Configuration Table (Default Configuration in Bold)

Power Supply Source	From Header Pin	To Header Pin	Power Supply Destination
SYS_VDD	J10-1	J10-2	VDD_MCU
VDD_EXT	J10-3	J10-4	VDD_MCU
VDD0P9	J10-5	J10-6	VDDUSB0P9_AP510L

Figure 15 shows the power sourcing for VDDH1, VDDH2, VDDH3, VDDH4, VDDH5, VDDRF_H, and VDDRF_PAH.

- VDDH1 and VDDH2 which are always sourced from VDD_MCU (Voltage depends on the selection on J10. By default they are 1.8 V).
- VDDH3 is always sourced from 1.8 V.
- VDDH4 and VDDH5 may be sourced from default 1.8 V (SYS_VDD) or 3.3 V (VDD_3V3).
- VDDRF_H and VDDRF_PAH are always sourced from 1.8 V (SYS_VDD).

This header can be used to measure current on any of the supplies.

**Figure 15. Power Supply Jumper Connections**

The J4 default jumper configuration is as shown in Figure 16 and Table 3.




Figure 16. J4 Default Jumper Configuration

Table 3: J4 Jumper Configuration (Default Configuration in Bold)

Power Supply Source	From Header Pin	To Header Pin	Power Supply Destination
VDD_MCU	J4-3	J4-4	VDDH1
VDD_MCU	J4-5	J4-6	VDDH2
SYS_VDD	J4-7	J4-8	VDDH3
SYS_VDD	J4-9	J4-10	VDDH4
VDD_3V3	J4-11	J4-12	VDDH4
SYS_VDD	J4-13	J4-14	VDDH5
VDD_3V3	J4-15	J4-16	VDDH5
SYS_VDD	J4-17	J4-18	VDDRF_H
SYS_VDD	J4-19	J4-20	VDDRF_PAH

13.1 USB 3.3 V and Display Load Switch Circuit

Figure 17 shows the USB and Display dual load switch circuit producing the voltage supplied to VDDUSB33_AP510L (for USB) and VDD18 (for Display).




Figure 18. J3 and J5 Voltage Test Point Headers

The J3 and J5 headers are as shown in Figure 19. The header guard may need to be removed before connecting to or probing the header pins.




Figure 19. Board View of J3 and J5 Voltage Test Points Headers

13.3 Measuring Current

Current consumption of the Apollo510 Lite Series EVB can be measured by connecting an ammeter between the corresponding DUT supplies. Refer to Figure 13 or Figure 15 to measure the current draw from the power supply of interest. Before using an ammeter, turn the power off, remove the corresponding jumper and install the ammeter properly prior to powering the board back on. When the current measurements have been completed, reposition the jumper at its former location.

13.4 Radio Subsystem Power Consumption Measurement for the Apollo510D Lite SoC

This section describes the procedure for measuring radio subsystem power consumption using the Apollo510D Lite SoC on Revision 3.0 of the EVB. It covers preparation of the EVB, connection to the Joulescope JS220, and current measurement.

13.4.1 Setup

1. Set up the hardware connection as shown below to measure the radio subsystem power consumption:
 - A. The EVB's power source is via the Main USB (J16) connected to a PC (used to program the binary). Perform the following setup before applying power.
 - B. Remove jumper between pin 19 (SYS_VDD) and pin 20 (VDDRF_PAH) on header J4.
 - C. Remove jumper between pin 17 (SYS_VDD) and pin 18 (VDDRF_H) on header J4.
 - D. Remove jumper between pin 1 (SYS_VDD) and pin 2 (VDD_MCU) on header J10.
 - E. Connect pin 20 (VDDRF_PAH) and pin 18 (VDDRF_H) on header J4 to pin 2 (VDD_MCU) on header J10 and to the Joulescope's "Current-" connector.
 - F. Connect pin 1 (SYS_VDD) on header J4 to the Joulescope's "Voltage+" connector and the "+Current" connector.
 - G. Connect the EVB ground test point TP23 to the Joulescope's "-Voltage" connector. (See "EVB Top View" on page 10.)




Figure 20. Joulescope to EVB Power Connections

2. Build and download the uart_hci_bridge.bin on the Apollo 510 Lite EVB.




Figure 21. Download Messages in J-Link SWO Viewer

3. Refer to the latest “Guidelines for RF Testing in Apollo-Blue Family” document for HCI command lists to run the test.

13.4.2 Measuring Baseline Current

1. Reset the radio using the HCI reset command (0x01 0x03 0x0C 0x00).
2. Check the average current/power reading for VDD_MCU/VDDRF_H/VDDRF_PAH on the Joulescope.

13.4.3 Measuring Radio RX Mode Current

1. Enable the Radio LE RX mode by the HCI_LE_Receiver_test command.
2. Check the average current/power reading for VDD_MCU/VDDRF_H/VDDRF_PAH on the Joulescope.
3. Disable the Radio LE RX mode by the HCI LE Test command (0x01 0x1F 0x20 0x00).

13.4.4 Setting HCI_LE_Receiver_Test Command Format

Table 4 lists the format and content of an example HCI LE Receiver test command for channel 5, 1 MHz RX frequency, modulation index 0, using opcode 0x2033: 0x01 0x33 0x20 0x03 0x05 0x01 0x00.

13.4.5 Setting HCI_LE_Test_End Command Format

Table 4: Example of HCI_LE_Receiver_Test Command Format

HCI Command Header	Opcode Low	Opcode High	Parameter Length	PHY	Frequency	Modulation Index
0x01	0x33	0x20	0x03	0x05	0x01	0x00

Table 5 lists the format and content of an example HCI LE Test End command with opcode 0x201F: 0x01 0x1F 0x20 0x00.

Table 5: Example of HCI_LE_Test_End Command Format

HCI Command Header	Opcode Low	Opcode High	Parameter Length
0x01	0x1F	0x20	0x00

13.4.6 Measuring Radio TX Mode Current

1. Set the specific TX power level with the vendor command of set LE transmit power level.
2. Enable the Radio LE TX Continuous wave without modulation mode with the HCI_LE_Transmitter_test command.
3. Check the average current/power reading for VDD_MCU/VDDRF_H/VDDRF_PAH on Joulescope.
4. Disable the Radio LE TX mode with the HCI LE Test command (0x01 0x1F 0x20 0x00).

The TX-mode current is equal to the measured current less the baseline current.

13.4.7 Setting LE Transmit Power Level Command Format

Table 6 lists the format and content of an example which sets the LE transmit power level to 0 dBm using opcode 0xFC83: 0x01 0x83 0xFC 0x01 0x00.

Table 6: Example of HCI_LE_Test_End Command Format

HCI Command Header	Opcode Low	Opcode High	Parameter Length	Power Level
0x01	0x83	0xFC	0x01	0x00

To set the power level to -2 dBm, the command would be: 0x01 0x83 0xFC 0x01 0xFE, as the power level is int8_t type and a negative number is represented in complement form. The enumerated type for the power level range would be as below:

```
typedef enum
{
    TX_POWER_LEVEL_MINUS_20P0_dBm = -20,
    TX_POWER_LEVEL_MINUS_18P0_dBm = -18,
    TX_POWER_LEVEL_MINUS_16P0_dBm = -16,
    TX_POWER_LEVEL_MINUS_14P0_dBm = -14,
```

```

TX_POWER_LEVEL_MINUS_12P0_dBm = -12,
TX_POWER_LEVEL_MINUS_10P0_dBm = -10,
TX_POWER_LEVEL_MINUS_8P0_dBm = -8,
TX_POWER_LEVEL_MINUS_6P0_dBm = -6,
TX_POWER_LEVEL_MINUS_4P0_dBm = -4,
TX_POWER_LEVEL_MINUS_2P0_dBm = -2,
TX_POWER_LEVEL_0P0_dBm = 0,
TX_POWER_LEVEL_PLUS_1P0_dBm = 1,
TX_POWER_LEVEL_PLUS_2P0_dBm = 2,
TX_POWER_LEVEL_PLUS_3P0_dBm = 3,
TX_POWER_LEVEL_PLUS_4P0_dBm = 4,
TX_POWER_LEVEL_PLUS_5P0_dBm = 5,
TX_POWER_LEVEL_PLUS_6P0_dBm = 6,
TX_POWER_LEVEL_PLUS_7P0_dBm = 7,
TX_POWER_LEVEL_PLUS_8P0_dBm = 8,
TX_POWER_LEVEL_PLUS_9P0_dBm = 9,
TX_POWER_LEVEL_PLUS_10P0_dBm = 10,
TX_POWER_LEVEL_PLUS_11P0_dBm = 11,
TX_POWER_LEVEL_PLUS_12P0_dBm = 12,
TX_POWER_LEVEL_PLUS_13P0_dBm = 13,
TX_POWER_LEVEL_INVALID,
} txPowerLevel_t;

```

13.4.8 Setting HCI_LE_Transmitter_test Command Format

Table 7 lists the format and content of an example to run a HCI LE Transmitter test command using channel 5, packet type 0x04, packet length 0x11, 1 MHz TX frequency, packet type 0x10 (continuous wave without modulation). The command using opcode 0x2034 would be: 0x01 0x34 0x20 0x04 0x05 0x11 0x10 0x01.

Table 7: Example of HCI_LE_Test_End Command Format

HCI Command Header	Opcode Low	Opcode High	Parameter Length	PHY	Parameter (Packet) Length	Packet Type	Frequency
0x01	0x34	0x20	0x04	0x05	0x11	0x10	0x01

14. EVB Known Issues

The eMMC and its passive components have been de-populated on this board revision due to supply constraints, but the pads are on the board if the user wants to use their own footprint compatible eMMC and passives components.

The following components need to be populated if eMMC is being used: U11, C81, C82, C83, C84, C85, R64, R65, and R66.

15. Ordering Information

Table 8: EVB Ordering Information

Device Name	Orderable Part Number	EVB Revision	SoC
Apollo510D Lite EVB	AP510DLEVB	3.0	Apollo510D Lite BGA



©2026 Ambiq Micro, Inc. All rights reserved.

Ambiq Micro, Inc.

6500 River Place Boulevard, Building 7,

Suite 200, Austin, TX 78730-1156

www.ambiq.com/

sales@ambiqmicro.com

<https://support.ambiqmicro.com>

+1 (512) 879-2850

QS-A510DL-3p0

Version 3.0

September 2026